



# K-FORCE® ELITE 47

## FULL LIGHT BAR

### Flash Pattern List

Half-Half Slow  
Half-Half Medium  
Half-Half Fast  
Half-Half Medium->Fast  
Half-Half Triple Burst  
Alternating 1-1 Slow  
Alternating 1-1 Medium  
Alternating 1-1 Fast  
Alternating 1-1 Medium->Fast  
Alternating 1-1 Triple Burst  
Alternating 2-2 Slow  
Alternating 2-2 Medium  
Alternating 2-2 Fast  
Alternating 2-2 Medium->Fast  
Alternating 2-2 Triple Burst  
Full Slow  
Full Medium  
Full Fast  
Full Medium->Fast  
Full Triple Burst  
Night-Rider Double Sweep Slow  
Night-Rider Double Sweep Fast  
Double-Pong  
Half Steady A – Half Blink B  
Half Steady B – Half Blink A  
Half-Half -> Full Blink  
Alternating 1-2 Slow  
Alternating 1-2 Fast  
Combo-Patrol  
Combo-Rapid  
Park Half-Half  
Park 1-1 Alternating  
Park Half-Half Double Blink  
Park 1-1 Alternating Double Blink

### Flash Pattern Shortcuts

- Hold for 2 seconds to toggle Steady Burn mode.
- Hold for 4 seconds to toggle Auto cycle through mode.

All rights reserved. No part of this Instruction Manual may be reproduced, distributed, transmitted, or otherwise shared in any form or by any means, including but not limited to photocopying, recording, electronic delivery, .PDF reproduction, or any other means of reproducing all or any part hereof without the express prior written consent of SpeedTech Lights, Inc, except for non-commercial purposes as permitted by United States copyright law. Customers of SpeedTech Lights, Inc, may download and print this Instruction Manual for use with products sold to the customer by SpeedTech Lights, Inc. However, no part of this Instruction Manual may be otherwise or subsequently reproduced, downloaded, disseminated, published, or transferred, in any form or by any means, except with the prior written consent of SpeedTech Lights, Inc.