

2809 Business Park Dr • Buda • TX • 78610


Phone 800.757.2581 • Fax 844.894.2652 • Email customerservice@speedtechlights.com


STL Windshield Visor Assembly and Mounting

Remove Contents From Package:




Take End Cap Bracket and Visor and Insert As Shown:





Take the Three (3) Screws and Secure End Cap Bracket to Visor:





Replace End Cap Screws With the Longer Screws That Come With the Visor:

