



K-FORCE® ELITE 75

FULL LIGHT BAR

Flash Pattern List

Half-Half Slow
Half-Half Medium
Half-Half Fast
Half-Half Medium->Fast
Half-Half Triple Burst
Alternating 1-1 Slow
Alternating 1-1 Medium
Alternating 1-1 Fast
Alternating 1-1 Medium->Fast
Alternating 1-1 Triple Burst
Alternating 2-2 Slow
Alternating 2-2 Medium
Alternating 2-2 Fast
Alternating 2-2 Medium->Fast
Alternating 2-2 Triple Burst
Full Slow
Full Medium
Full Fast
Full Medium->Fast
Full Triple Burst
Night-Rider Double Sweep Slow
Night-Rider Double Sweep Fast
Double-Pong
Half Steady A – Half Blink B
Half Steady B – Half Blink A
Half-Half -> Full Blink
Alternating 1-2 Slow
Alternating 1-2 Fast
Combo-Patrol
Combo-Rapid
Park Half-Half
Park 1-1 Alternating
Park Half-Half Double Blink
Park 1-1 Alternating Double Blink

Flash Pattern Shortcuts

- Hold for 2 seconds to toggle Steady Burn mode.
- Hold for 4 seconds to toggle Auto cycle through mode.

All rights reserved. No part of this Instruction Manual may be reproduced, distributed, transmitted, or otherwise shared in any form or by any means, including but not limited to photocopying, recording, electronic delivery, .PDF reproduction, or any other means of reproducing all or any part hereof without the express prior written consent of SpeedTech Lights, Inc, except for non-commercial purposes as permitted by United States copyright law. Customers of SpeedTech Lights, Inc, may download and print this Instruction Manual for use with products sold to the customer by SpeedTech Lights, Inc. However, no part of this Instruction Manual may be otherwise or subsequently reproduced, downloaded, disseminated, published, or transferred, in any form or by any means, except with the prior written consent of SpeedTech Lights, Inc.